

TURN-AMENT FISHING

Instruction Manual
Model #7817



 **GOLD MEDAL®**

FUNFOOD EQUIPMENT & SUPPLIES

Cincinnati, OH 45241-4807 USA

SAFETY SHEET

	⚠ WARNING To avoid injury, do not sit or climb on games. Do NOT use this game as a table.
	⚠ DANGER Machine must be properly grounded to prevent electrical shock to personnel. Do NOT immerse in water. Always unplug the equipment before cleaning or servicing.
	⚠ WARNING Any alterations to this equipment will void the warranty and may cause a dangerous situation. NEVER make alterations to the equipment. Make sure all machine switches are in the OFF position before plugging the equipment into a receptacle.
	⚠ CAUTION Carefully read all installation and operating instructions before operating the equipment.

NOTE

The information, specifications and illustrations contained in this manual represent the latest data available at time of publication. Right is reserved to make changes as required at the discretion of Gold Medal Products Company without notice.


INSTALLATION INSTRUCTIONS

CHECKING SHIPMENT

The Turn-ament Fishing game is shipped in two corrugated cartons. One carton will include the base and the legs. The other carton will include the insert, decal, and game pieces. Unpack all cartons and check thoroughly for any damage, which may have occurred during transit. Damage claims should be filed immediately with the transportation company.

ASSEMBLY

Step 1. Assemble legs to the base by inserting the tapered ends of the leg into the tapered holes on the underside of the game base.




Step 2. Place assembled insert into base. Plug wall transformer into insert and then into wall outlet.



APPLY GAME DECAL

1. The decal has a magnetic backing.
2. Place magnetic side of decal onto metal plate on back surface of game base.



OPERATING INSTRUCTIONS

1. The player holds the fishing pole.
2. Player must use hook attached to fishing pole to catch hook on vertical fish.
3. Award prizes based on color of fish caught. Optionally, use magic marker to number fish and award prize based on number caught.

CARE AND CLEANING

As required, soap and water may be used to clean the game base, legs and inserts. Wipe dry with a clean dry cloth.

ORDERING SPARE PARTS

1. Identify the worn or broken part by checking it with the illustrations and parts list.
2. When ordering parts, include part number, part name, and quantity required.
3. Include you model name and machine serial number (found on nameplate) with your order.
4. Address orders to:

Parts Department
Gold Medal Products Co.
10700 Medallion Drive
Cincinnati, Ohio 45241-4807

or, place orders at:

(800) 543-0862
(513) 769-7676
Fax: (513) 769-8500
E-mail: info@gmpopcorn.com
www.gmpopcorn.com

PARTS LIST

ItemNb	Part Nb	Description
1	52111	Legs (Yellow Only)
2	7750	Base (Red)
3	7752	Base (Green)
4	7751	Base (Blue)
5	7753	Base (Yellow)
6	52102	Wall Transformer
7	52109	Power Jack Assembly
8	52270	Fishing pole
9	52301	12VDC Motor
10	52308	Jack Mount Plate
11	52309	Fish Set - Vertical
12	52310	Insert
13	52311	Turntable
14	52312	Bracket Weldment
15	52315	Motor Mount Bracket
16	52317	Magnetic Sign
17	52320	Cup Hook
18	52325	Hook Bobbin

SPECIFICATIONS

Game Base with Legs attached:


Height: 35 inches

Width: 41-1/4 inches

Depth: 29-1/2 inches

Inserts: 23 inches X 23 inches

ELECTRICAL SCHEMATIC



WARRANTY

WE WARRANT to the original purchaser the Gold Medal equipment sold by us to be free from defects in material or workmanship under normal use and service. Our obligation under this warranty shall be limited to the repair or replacement of any defective part for a period of six (6) months from the date of sale to the Original Purchaser with regard to labor and two (2) years with regard to parts and does not cover damage to the equipment caused by accident, alteration, improper use, voltage, abuse, or failure to follow instructions.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESSED OR IMPLIED, AND OF ALL OTHER OBLIGATIONS OR LIABILITIES ON OUR PART, INCLUDING THE IMPLIED WARRANTY OF MERCHANTABILITY. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. We neither assume, nor authorize any other person to assume for us, any other obligation or liability in connection with the sale of said GOLD MEDAL equipment or any part thereof.

The term "Original Purchaser" as used in this warranty shall be deemed to mean that person, firm, association, or corporation who was billed by the GOLD MEDAL PRODUCTS COMPANY, or their authorized distributor for the equipment.

THIS WARRANTY HAS NO EFFECT AND IS VOID UNLESS THE ORIGINAL PURCHASER FIRST CALLS GOLD MEDAL PRODUCTS COMPANY AT 1-800-543-0862 TO DISCUSS WITH OUR SERVICE REPRESENTATIVE THE EQUIPMENT PROBLEM, AND, IF NECESSARY, FOR INSTRUCTIONS CONCERNING THE REPAIR OR REPLACEMENT OF PARTS.

NOTE: This equipment is manufactured and sold for commercial use only.



GOLD MEDAL PRODUCTS COMPANY
10700 Medallion Drive
Cincinnati, Ohio 45241-4807 USA